

MANUFACTURING PLAN

RAW MATERIAL STOCK: 1/2" Aluminum Hex

STEP	PROCESS DESCRIPTION	MACHINE	FIXTURE	TOOL(S)	SPEED (RPM)
1	Cut down to 2.5"	Band Saw	-	-	300 ft/min
2	Deburr the ends of the surfaces	Lathe	-	File	-
3	Place in lathe and face off to get a machined surface	Lathe	Collet	-	
4	Deburr the part	-	Collet	File	750
5	Remove part from lathe and flip	-	-	-	-
6	Repeat steps 3 and 4	Callipers	-	-	-
7	Remove part from lathe and measure with callipers	Lathe	-	-	-
8	touch off with parting tool and zero x. Cut to length taking passes of 0.050" or less Trim down to 2.25"	Lathe	Collet	Parting Tool	750
9	Trim down to 2.25"	Lathe	Collet	Parting Tool	750
10	Mill down 1.85" to a diameter of .25"	Lathe	Collet	Cutting Tool	
11	Centerdill	Lathe	Collet	Denter Drill with Drill chuck	100
12	Drill .068" drill to depth of 1.85;;	Lathe	Collet	Drill with Drill chuck	700
13	Deburr the part	File	-	File	-
14	Use edgefinder to locate X and Y coordinates of edges	Mill	-	Edge Flnder	1000
15	Use center drill Drill a thru hole .26" in from the thick end of the shaft with a major diameter of .089"	Mill	Vise 1.375"	#43 Drill	1000
16	Drill a thru hole .15" off the thin end with a .063" diameter	Mill	Vise 1.375"	1/16 Drill	1000

.

В

SHEET 2 OF 2

В